

WARNING READ THIS BEFORE INSTALLING

FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY CAUSE SERIOUS INJURY OR DEATH

You have purchased the finest Standard Layback Containment Seat available. These components (when installed correctly) are designed to reduce injury-producing movement of the upper body and head during a racing impact, but no device or component can prevent all injuries that may occur in auto racing. Auto racing remains a very dangerous sport regardless of any protective devices you may use. Please read the instructions very carefully and if you have any questions please contact Kirkey Racing Fabrication (800) 363-4885

Please read instructions before you start assembling seat.

You have the choice of three different positions that you can set the height of the head and shoulder restraints, (see fig 1). Ideally you want the head restraint positioned level with the driver's cheekbone, (see fig 2). Have the driver look to the left and to the right to ensure that their peripheral vision is not obstructed. If peripheral vision is obstructed adjust accordingly. With the restraint at the proper height fasten the back of the seat to the bottom using the pre-punched holes and eight of the 3/16" x 1/2" bolts provided. To make alignment easier do not tighten bolts until they are all in place.

DO NOT OVERTIGHTEN Parts list:

3/16" x ½" bolts 8 3/16 lock nuts 8





Mounting instructions:

For the bottom there are two ways that you can mount this seat. You can use four bolts directly through the bottom, (spread the bolts out as far as possible to distribute the load). Or you can do a side mount using part number 99204, (see fig 3). For the back we recommend at least four bolts here as well using the pre-punched holes in the back of the seat. We also make a bracket for this as well, (see fig 4). The part number for the rear bracket is 99205. If you are not qualified to perform such fabrication have the installation done by an expert familiar with the requirements of such installation.



Part # 99204



Part # 99205





70/71 Series Installation Instructions