



## Installation Instructions



### Part # 11249570 - 68-70 GM A-Body Steering Kit

#### Recommended Tools



#### Major Components .....In the box

QTY	Part Number	Description
2	90000728	Tie Rod Adjuster
2	99800002	5/8"-18 Right Hand Jam Nut
2	99800003	5/8"-18 Left Hand Jam Nut
2	90003027	Inner Tie Rod - 8.625" Long (from grease zerk) - 5/8"-18 Left Hand Thread
2	90003020	Outer Tie Rod - 8.625" Long (from grease zerk) - 5/8"-18 Right Hand Thread
1	90003005	Idler Arm
1	90003034	Centerlink

#### NOTES:

This Tie Rod Adjuster is designed to take place of the OEM steel sleeve.

One end of the adjuster has a **groove** cut in it, this is the **LEFT HAND** threaded side.

When installing the Tie Rod Adjuster, use antisieze compound on the threads.

**FOR YOUR SAFETY, THE TIE RODS NEED A MINIMUM 15/16" OF THREAD ENGAGEMENT INTO THE TIE ROD ADJUSTER.**

[www.ridetech.com](http://www.ridetech.com)

