



## Installation Instructions



### Part # 11249571 - 1971-1972 GM A-Body Steering Kit

#### Recommended Tools



#### Major Components .....In the box

QTY	Part Number	Description
2	90000138	Tie Rod Adjuster
2	99800000	11/16"-16 Right Hand Jam Nut
2	99800001	11/16"-16 Left Hand Jam Nut
2	90003014	Inner Tie Rod - 8.625" Long(from grease zerk) - 11/16"-18 Left Hand Thread
2	90003023	Outer Tie Rod- 8.625" Long(from grease zerk) - 11/16"-18 Right Hand Thread
1	90003005	Idler Arm
1	90003034	Centerlink

#### NOTES:

This Tie Rod Adjuster is designed to take place of the OEM steel sleeve.

One end of the adjuster has a **groove** cut in it, this is the **LEFT HAND** threaded side.

When installing the Tie Rod Adjuster, use antisieze compound on the threads.

**FOR YOUR SAFETY, USE THE SIGHT HOLES IN THE SIDE OF THE TIE ROD ADJUSTER TO ENSURE PROPER THREAD ENGAGEMENT.**

[www.ridetech.com](http://www.ridetech.com)

