



Part # 11380201 - 99-06 Silverado CoilOver System

Front Components:

11382899	Front Lower StrongArms
11383699	Front Upper StrongArms
11389300	Front Spindles and Caliper Brackets
11383510	Front Coilovers
11389100	Front MuscleBar




Rear Components:

11387199	Rear StrongArm System
11386510	Rear Coilover Instructions

Miscellaneous Components:

85000000	Spanner Wrench
----------	----------------

Recommended Tools



99-06 Silverado Coilover System Installation Instructions

Table of contents

Pages 2-4.....	Front Coilovers
Pages 5-8.....	Lower StrongArms
Pages 9-11.....	Upper StrongArms
Pages 12.....	Spindles
Pages 13-15.....	Front MuscleBar
Pages 16-34.....	Rear 4Link
Pages 35-36.....	Rear CoilOver
Pages 37-38.....	Final Adjusting and Preloading the Spring



THIS KIT WILL NOT WORK ON TRUCKS WITH TORSION BARS!!





Part # 11383510 - 99-06 Silverado Front HQ Series CoilOvers

Recommended Tools



1999-2006 Silverado HQ Series Front CoilOvers Installation Instructions

Table of contents

Page 3..... Included components

Page 4..... CoilOver Installation

ShockWave Dimensions:

Center of bearing to Center of bearing:

Compressed: 10.13"

Ride Height: 12.50"


Extended: 14.23"





Major ComponentsIn the box

Item #	Part #	Description	QTY
1	24149999	4.1" Stroke HQ Series Shock	2
2	90002024	Upper Shock Eyelet	2
3	59100800	CoilSpring 10" 800lb	2
4	70010828	Delrin Spring Washer	2
5	90002222(kit)	Lower Spring Adjuster Nut (90002222 kit)	2
6	90002222(kit)	Adjuster Nut Locking Screw (90002222 kit)	2
7	90002222(kit)	Upper CoilSpring Retaining Plate (90002222 kit)	2
8	90002222(kit)	CoilSpring Plate Retaining Ring (90002222 kit)	2
9	90000097	Upper Mounting Plate	2
10	90002043	Upper Shock Bearing Spacers	4
11	90002062	Lower Bearing Spacers (INCLUDED WITH STROGARMS)	4
12	90000359	Lower Control Arm T-Bushing	2
13	99501018	1/2"-13 x 1 1/2" Carriage Bolt	2
14	99501010	1/2"-20 x 2 1/4" Hex Bolt	2
15	99502003	1/2"-20 Thin Nylok Nut	2
16	99502001	1/2"-13 Nylok Nut	2
17	99503001	1/2" Flat Washer	4
	90001994	5/8" ID Bearing (installed in shock body & eyelet)	4
	90001995	Bearing Snap Ring (installed in shock & eyelet body)	8






CoilOver Installation

4.



5.



1. Raise and support truck at a safe, comfortable working height. Let the front suspension hang freely.

2. Remove the coil spring, shock absorber, bump stop, upper control arm, and lower control arm. Refer to factory service manual for proper disassembly procedure.

3. Install the CoilSpring on the CoilOver per the instructions on Page 4.

4. Insert the carriage bolt through the square hole in the upper mount. Insert a NARROW Bearing Spacer into each side of the Upper Eyelet. Slide the Eyelet of the CoilOver with the Spacers installed into the Upper Mount. Bolt the top of the CoilOver to the upper mount using a 1/2" x 2 1/4" bolt and Nylok jam nut.

5. Raise the CoilOver up to the coil spring mount with the carriage bolt sticking through the factory shock hole. The hole in the frame is larger than the bolt, so a step washer is supplied. This should be installed on top of the frame, followed by a 1/2" Nylok nut.

Note: The kidney bean shaped cutout in the upper bracket will match a protrusion in the coil spring pocket. This will clock the CoilOver so that when the suspension moves the bearing will rotate on the bolt. **If this is not installed properly it will damage the CoilOver.**



Part # 11382899

1999-2006 Silverado Lower ShockWave/CoilOver StrongArms

Recommended Tools



1999-2006 Silverado Lower StrongArms Installation Instructions

Table of contents

Page 6..... Included components
Page 7..... Getting Started
Page 8..... PosiLink Installation

THIS KIT IS DESIGNED TO RAN WITH A 2" DROP SPINDLE.
RIDETECH PART #: 11389300

www.ridetech.com
812-482-2932






Lower Control Arm ComponentsIn the box

Item #	Part Number	Description	QTY
1	90000106	Driver Lower Control Arm (Shown)	1
1	90000107	Passenger Lower Control Arm	1
2	90000198	3.0" Inner Sleeve	4
3	90000199	3.5" Inner Sleeve	4
4	70010759	Delrin Bushing - with 2" Diameter Ledge	8
5	90002062	ShockWave/CoilOver Bearing Spacers	4
6	99502001	1/2" Nylok Nut	2
7	99501024	1/2"-13 x 3 1/4" Hex Bolt	2
8	90000901	Lower Balljoint Assembly	2
9	90000921	12mm 90 Degree PosiLink (PosiLink Assembly)	2
10	90000922	12mm Straight PosiLink (PosiLink Assembly)	2
11	90000095	PosiLink T-Bushing	2
12	90000096	PosiLink Spacer (PosiLink Assembly)	2
13	99125002	M12 - 1.75 x 65mm Threaded Rod (PosiLink Assembly)	2
14	99433002	7/16" Flat Washer	6
15	99122001	M12 - 1.75 Nylok Nut	4


Driver Side Shown





Getting Started.....

2.




1. Remove the Lower Control Arms, CoilSprings, Shocks, and sway bars linkage. Refer to the factory service manual for disassembly procedure.

2. After removing the factory lower control arm, clean the bushing mounting surfaces on the frame. The Control Arms are marked "D" for Driver and "P" for Passenger. The Balljoint Pin points down and the Sway bar mount is on the front side of the arm. Fasten the lower arm to the frame with the OEM hardware.

Note: On some trucks the frame brackets may be pinched and will need to be spread back apart to allow the bushing to slide in.

3.



3. Raise the lower arm up to the CoilOver and bolt them together using the 1/2" x 3 1/2" bolt, flat washer, and nylok supplied w/ the lower arms. An aluminum spacer will be on each side of the bearing. Torque to 75 ftlbs.

4.



4. Install the T-Bushing on the Straight PosiLink end with the Large OD against the PosiLink. Insert the assembly into the swaybar with the threads pointing up. Install a 7/16" Flat Washer followed by a M12-1.75 Nylok Nut. Torque to 50 ftlbs.




PosiLink Installation



5. Install a 7/16" Flat Washer onto the threads of the 90 Degree PosiLink. Insert the PosiLink into the swaybar tab on the control arm with the threads pointing to the FRONT of the truck. Install a 7/16" Flat Washer and M12 - 1.75 Nylok Nut and torque to 50 ftlbs.

5. **Image 6** illustrates the correct assembly and orientation of the PosiLink.







Part # 11383699

1999-2006 Silverado Upper StrongArms

Recommended Tools



1999-2006 Silverado Upper StrongArms Installation Instructions

Table of contents


Page 10.....	Included components
Page 11.....	Getting Started
Page 12.....	PosiLink Installation





Lower Control Arm ComponentsIn the box

Item #	Part Number	Description	QTY
1	90000630	Upper Control Arms	2
2	90000902	Upper Balljoint	2
3	70010759	Delrin Control Arm Bushing	8
4	90001097	Delrin Bushing Inner Sleeve	4
5	90000902 KIT	Upper Balljoint Bolts	8
6	90000902 KIT	Upper Balljoint Hex Nuts	8
7	90000902 KIT	Upper Balljoint Lock Washers	8



Getting Started.....



1. Remove the Upper Control Arms. The Camber Bolts need to be reinstalled in the same positions they are removed from. We recommend marking their positions for reassembly. Refer to the factory service manual for disassembly procedure. After removing the factory upper control arm, clean the bushing mounting surfaces on the frame.

2. The Driver and Passenger Control Arms are identical. Insert the Control Arm into the OEM frame mount with the balljoint stud pointing down. The Gussets of the Balljoint Plate should also point down.




Getting Started.....

3.




3. Bolt the arm to the frame using the factory camber bolts.

4.



4. Insert the balljoint into the spindle. You will need to clearance the bottom of the taper with a 1/2" Drill bit. Refer to **Images 4 & 5**.

5.



5. Image 5 illustrates the cleared spindle taper. The drawing is exaggerated for illustration purposes.

6. Slide the balljoint pin into the spindle and install the castle nut on each one. Torque the balljoint nuts and install cotter pins in each one.




Balljoint nut Torque Specs:

Torque to 50 ft lbs and then tighten nut to align cotter pin hole not exceeding 90ft lbs.



Part # 11389300 - 1999-2006 Silverado Drop Spindles

Recommended Tools



1999-2006 Silverado Drop Spindles Installation Instructions

Installation

Refer to the instructions included with the spindles except;

Balljoint nut Torque Specs:

Upper: Torque to 50 ft lbs and then tighten nut to align cotter pin hole not exceeding 90ft lbs.





Part # 11389100 - 1999-2006 Silverado Front MuscleBar



Recommended Tools



1999-2006 Silverado Front MuscleBar Installation Instructions

Table of contents

Page 14..... Included Components and Hardware List

Page 15..... MuscleBar Installation



Major ComponentsIn the box

Part #	Description	QTY
90001768	Front MuscleBar	1

HARDWARE KIT COMPONENTS #90002759

Description	QTY
Frame Bushing	2
Frame Bushing Strap	2
Lithium Grease	1
End Link Kit (for OEM Arms only)	2
End Link Bushings	8
End Link Spacer	2
End Link Bushing Washers	8
End Link Bolt & Nut Kit	2

Getting Started.....

Remove the OEM Swaybar to prepare for the MuscleBar SwayBar installation.

If using Ridetech StrongArms, the PosiLink Assembly is included with the lower StrongArms.

If you are using the OEM control arms, the end link kit provided with this kit will be used.

1. Use the supplied grease for the poly frame bushings. Apply a thin coat of grease to the inside of the bushings.



2. Open up the Poly SwayBar Bushings and install them over the MuscleBar.



MuscleBar Installation




3. Slide the MuscleBar into position on the truck. The SwayBar Arms will be above the steering linkage. Install Bushing Straps Over the Poly MuscleBar Bushing and bolt them in place using the OEM hardware. Do not tighten the hardware until the PosiLinks are hooked up to the MuscleBar.



STRONGARM LINKAGE

4. Install the T-Bushing on the Straight PosiLink end with the Large OD against the PosiLink. Insert the assembly into the swaybar with the threads pointing up. Install a 7/16" Flat Washer followed by a M12-1.75 Nylok Nut. Torque to 50 ftlbs. Next, tighten the bushing mount hardware to 30 ftlbs.



OEM CONTROL ARM LINKAGE

5. Install the End Links. Use Diagram "5" for proper installation. Tighten the Hex Nut enough to slightly compress the Bushings.



Part # 11387199

1999-2006 Silverado Rear Bolt-On Wishbone Suspension System

Recommended Tools



1999-2006 Silverado Rear Suspension Installation Instructions

Table of contents

Page 17-18.....	Included Components
Page 19.....	Hardware List & Disassembly
Page 20.....	Disassembly
Page 21-26.....	C-Notch & Wishbone Crossmember Installation
Page 26.....	Crossmember & Lower Axle Mount Installation
Page 27.....	Installing Lower Axle Mount & Lower Bars
Page 28.....	Wishbone Axle Mount Installation
Page 29.....	Wishbone and Shockwave/CoilOvers Installation
Page 30.....	Shockwave/CoilOvers & Carrier Bearing Mount
Page 31.....	Carrier Bearing Mount, E-Brake Cable Relocation
Page 32-33.....	E-Brake Cable Relocation
Page 33-34.....	Bed Modification






Major ComponentsIn the box

Item #	Part #	Description	QTY
1	90000207	Driver C-Notch	1
2	90000208	Passenger C-Notch	1
3	90002776	Lower Axle Bracket	2
4	90002779	Rear Upper Control Arm Mount Crossmember	1
5	90002780	Rear Upper Wishbone - Set to 16 5/8"	1
6	90002781	Rear Upper Control Arm Differential Mount	1
7	90002804	C-Notch Nut Plate - Driver	1
8	90002805	C-Notch Nut Plate - Passenger	1
9	90001038	Lower Bars	2
10	90000311	C-Notch Spacer Plate - 1999 & 2000 Trucks	2
11	90000209	Carrier Bearing Spacer - used on carrier bearing equipped trucks	1
12	90000310	Transmission Spacer	1
13	70013364	RH R-Joint Threaded Housing	1
	90001617	5/8" Shock Stud	2
	90001624	Aluminum Lower Shock Mount	2
	90002067	Lower Shock Bearing Spacers	4
	90002883	Lower 4 Link Bar Front T-Bushing	4
	70013334	R-Joint Spacers - upper control arm and rear lower bar	6
	70013769	R-Joint Spacer - Lower Bars - Front	4
	70010827	Delrin Bushings - installed in upper control arm	4
	90000549	Delrin Bushing Inner Sleeves - installed in upper control arm	2
	99752004	3/4"-16 Jam Nut - Installed on Upper Control Arm	1
	90001082	Short Bumpstops with Hardware	2
	70013497	U-Bolt- 5/8-18 x 3.13 x 5 w/2" Thread	4
R-Joint Components - (Installed in bar ends and front of wishbone)			
	70013279	Retaining Ring	5
	70013280	Wavo Wave Spring	5
	70013275	R-Joint Center Ball	5
	70013276	R-Joint Composite Center Ball Cage	5

New R-Joints will be quite stiff (75-90 in/lbs breakaway torque) until they "break in" after a few miles of use. After the break in period they will move much more freely. Because the composite bearing race contains self lubricating ingredients, no additional lubrication is needed or desired. Any additional lubrication will only serve to attract more dirt and debris to the R-Joint and actually shorten its life.




Major ComponentsIn the box




R-JOINT SPACER INSTALLATION

Install the Spacers by inserting the SMALL side of the SPACER into the Center Pivot Ball. Push them in until they bottom out and stop.

LOWER FRONT R-JOINT



ALL OTHER R-JOINTS



New R-Joints will be quite stiff (75-90 in/lbs breakaway torque) until they "break in" after a few miles of use. After the break in period they will move much more freely. Because the composite bearing race contains self lubricating ingredients, no additional lubrication is needed or desired. Any additional lubrication will only serve to attract more dirt and debris to the R-Joint and actually shorten its life.



Hardware ListIn the box (Kit# 99010080)

The Hardware Kit contains bags to help aid in selecting the correct hardware for the component being installed. The hardware list shows how the hardware is bagged.

QTY	Part Number	Description	QTY	Part Number	Description
LOWER 4LINK BARS			UPPER CONTROL ARM DIFFERENTIAL MOUNT		
2	99621007	5/8" x 5" SAE GR8 Bolt	7	99081006	M8 x 35mm Gr10.9
2	99621004	5/8" x 3" SAE Gr. 8 Bolt	7	99083001	M8 Flat Washer
4	99622006	5/8" SAE Nylok Jam Nut	7	99083002	M8 Split Lock Washer
8	99623001	5/8" SAE Flat Washer	UPPER SHOCK MOUNTING		
UPPER CONTROL ARM CROSSMEMBER			2	99501064	1/2" x 2 3/4" USS Bolt Gr. 8
6	99431021	7/16" x 1 1/4" USS Bolt	2	99502009	1/2" USS Nylok Nut Gr. 8
12	99433005	7/16" SAE Flat Washer	4	99503012	1/2" SAE Flat Washer Gr. 8
6	99432010	7/16" USS Nylok Nut	UPPER CONTROL ARM MOUNTING		
2	99501063	1/2"-13 X 4 1/4" Hex Bolt	1	99621004	5/8" x 3" SAE Gr. 8 Bolt
2	99502009	1/2"-13 Nylok Nut	1	99622006	5/8" SAE Nylok Jam Nut
4	99503012	1/2" SAE Flat Washer	2	99623001	5/8" SAE Flat Washer
"C" NOTCH MOUNTING -			2	99501025	1/2"-13 x 3 1/4" Hex Bolt
38	99431021	7/16" x 1 1/4" USS Bolt	2	99502009	1/2"-13 Nylok Nut
26	99432010	7/16" USS Nylok Nut	4	99503012	1/2" SAE Flat Washer
64	99433005	7/16" SAE Flat Washer	CARRIER BEARING MOUNT		
12	99433003	7/16" Split Lock Washer	4	99371003	3/8"-16 X 1" Hex Bolt
LOWER SHOCK MOUNT			4	99372002	3/8"-16 Nylok Nut
2	99501019	1/2"-13 x 1 1/4" Hex Bolt	8	99373003	3/8" SAE Flat Washer
2	99501046	1/2"-13 x 1 3/4" Hex Bolt	AXLE BRACKET TO AXLE		
4	99502001	1/2"-13 Nylok Nut	8	99622013	5/8" SAE High Nut
4	99503001	1/2" SAE Flat Washer	8	99623010	5/8" SAE Flat Washer

Disassembly

Congratulations on your purchase of the Ridetech Rear Wishbone System. This system has been designed to give your truck excellent handling along with a lifetime of enjoyment. Some of the key features of this system: C-notches to give your suspension the travel it needs at the lowered height, 3Link setup to replace the leaf spring and provide better control of the rear axle, upper wishbone to eliminate the side-to-side movement of the differential, and the biggest feature of all, it allows the use of Shockwaves or CoilOvers.

Note: This system is designed for use with the Ridetech Shockwaves or CoilOvers. **The factory shocks and springs or the factory sway bar will not fit this 4Link.**




Disassembly

1. Raise the vehicle to a safe and comfortable working height and support it by the frame. You will need to be able to move the rear differential up and down. Use a jack under the rear axle so it can be raised and lowered as needed during the install.
2. **Remove the bed, retaining the hardware for reassembly. This kit can NOT be installed with the bed on. The bed requires minor modifications before reinstalling it.**
3. Remove the leaf springs and shock absorbers. Refer to the factory service manual for proper disassembly procedures.



4. The Brake Line Bracket will need to be removed from the top of the driver side frame rail. This will be reattached later.




5. Unbolt the emergency brake cable bracket from the driver side frame rail. It is located between the axle and the front leaf spring hanger. Retain the hardware for reassembly.



"C" Notch Installation



6. To allow maximum drop on this truck, the frame must be notched. The template for the notch will locate off of the 2 large oval holes. Use the supplied "C" Notch template to mark out the frame for cutting. Before cutting out the frame, support the frame in front of and behind the "C" Notch area. We suggest doing one side at a time. The tall end of the template is located to the front of the truck.



7. Use the supplied Template to mark the cut lines on the frame, then drill out the two corners with a 1/2" drill bit. This will give the cut a round edge and eliminate the possibility for stress fractures. Then cut the notch with a saw-z-all, cutoff wheel, or plasma cutter. Grind all edges smooth. Check the inside of the frame for wires or lines before drilling or cutting.



99 ONLY!!!

8. We have come across some frames that have a protrusion stamped in the frame above the axle. This will need to be flattened out to get the c-notch fitting tightly. We did this by extending the horizontal cut forward to the end of the protrusion then cutting straight down to the bottom of the frame. After the frame is cut, use a hammer or vise grips to bend the protrusion flat. Refer to **Image 8**.



"C" Notch Installation



9. After cutting, slip the c-notch over the frame to check the fitment.



10. The front edge of the C-Notch should be 4 1/2" from the oval hole in front of it. Trim the opening to move the c-notch forward or backward to achieve 4 1/2".




11. Use a 7/16" Drill bit to drill the holes in the side of the frame. DO NOT DRILL THE HOLES WHERE THE EMERGENCY BRAKE CABLE BRACKET BOLTED OR THE TOP AND BOTTOM OF THE C-NOTCH. There are 10 holes in the side that need to be drilled.



"C" Notch & Upper Crossmember Installation



12. After drilling the holes in the side for the frame, remove the C-notch to insert the front nut plate. **Image 12** shows the Driver Nut Plate. The top tab is bent to the inside of the frame to allow it to be held in place. After inserting the nut plate, reinstall the C-notch. Install a 7/16" Lock Washer, & 7/16" Flat Washer on (6) 7/16" x 1 1/4" Bolts. Hold the nut plate in place and insert the bolts/washer through the c-notch and frame threading them into the nut plate. Repeat on the other side. **LEAVE THE HARDWARE LOOSE.**



13. Install a 7/16" Lock Washer, & 7/16" Flat Washer on (4) 7/16" x 1 1/4" Bolts. Install them in the rear 4 holes of the c-notch. Install a 7/16" Flat Washer and 7/16" Nylok Nut on each bolt sticking through the frame. Repeat on the other side. **LEAVE THE HARDWARE LOOSE.**


Repeat Steps 6-13 on the other side.



14. Install the Wishbone cross member. The center mount of the crossmember will slip onto the factory crossmember tube. The driver and passenger flanges will bolt to the front 3 holes of each c-notch. Install a 7/16" Flat Washer on each of (6) 7/16" x 1 1/4" Bolts. Insert (3) bolt/washers in the front (3) holes of the c-notch and through the flange of the crossmember. Install a 7/16" Flat washer and 7/16" Nylok Nut on the threads sticking through the c-notch/flange. **DO NOT TIGHTEN.**



"C" Notch Installation



15. Tighten all of the c-notch side bolts. After tightening the side bolts, tighten the crossmember bolts. Torque to 50 ftlbs.



16. Reinstall the emergency brake cable bracket using the OEM hardware.



17. Use a 7/16" Drill bit to drill the remaining holes in the top and bottom of the frame. Install a 7/16" Flat Washer on the remaining 7/16" x 1 1/4" Bolts. Insert bolt/washers in the drilled holes of the c-notch. Install a 7/16" Flat washer and 7/16" Nylok Nut on the threads sticking through the c-notch/frame. DO NOT TIGHTEN.



"C" Notch & Crossmember Installation



18. Use a 7/16" drill bit to drill out the rear hole of the OEM Brake Line Bracket.



19. Remove the nut and washer from the 2nd from rear top bolt of the driver side c-notch. Install the brake line bracket on the bolt and reinstall the nut and washer. **If 1999 - 2000, continue on step 20.** If your truck is 2001 and newer, tighten the top and bottom c-notch hardware to 50 ftlbs then skip to step 21. If 1999 - 2000, continue on step 20.



1999-2000 ONLY

20. The 1999 & 2000 model year trucks have a slightly shorter frame rail height than the newer trucks. The kit includes (2) spacers to fill the gap that is on the bottom rear of the c-notch. Insert a spacer in the gap of the driver and passenger side c-notches. Tighten the top and bottom hardware to 50 ftlbs.




Crossmember & Lower Axle Mount Installation



21. Drill the front 2 Crossmember holes using a 1/2" Drill bit. It is best to drill the top holes from the top and the bottom holes from the bottom. This will insure they line up.



22. Install a 1/2" Flat Washer on each of (2) 1/2"-13 x 4 1/4" Bolts. Insert the (2) Bolt/washer in the drilled holes **FROM THE BOTTOM WITH THE THREADS STICKING UP**. Install a 1/2" Flat Washer and 1/2"-13 Nylok Nut on the threads sticking up of each bolt. Torque to 50 ftlbs.



23. The Axle Mounts are the same for driver and passenger sides. Install a supplied 5/8" U-bolt on each side of the OEM leaf spring pad. Slide an Axle Mount on the U-bolts with the top tabs inserted into the leaf spring pad. Hold the mount in place and install a 5/8" Flat Washer and 5/8" High Nut on the threads of the u-bolts sticking through the axle mount. Tighten the nuts evenly in a criss-cross fashion making sure the tabs of the axle mount are touching the leaf spring pad evenly. Torque the nuts in a criss-cross fashion to 60 ftlbs. Repeat on the other side.



Installing Lower Shock Mount & Lower Bars



24. The Lower Shock Mount attaches with (1) 1/2"-13 x 1 1/4" Hex Bolt, (1) 1/3"-13 x 1 3/4" Hex Bolt, & (2) 1/2" Flat Washer, & (2) 1/2"-13 Nylok Nuts. The Lower Mount gets attached to the 2nd and 3rd hole up from the bottom of the Axle Mount. When the Shock Mount is installed correctly, the bottom of the Lower Shock Mount is 1/8" above the bottom of the Axle Mount. Insert the Bolts through the Aluminum Shock Mount with the 1 1/4" long bolt in the top hole, 1 3/4" in the bottom hole. Insert the bolts through the Axle Mount and install the Flat Washers & Nylok Nuts on the Threads sticking through. Repeat on both sides and torque the Bolts/Nuts to 75 ftlbs. Install a 5/8" Flat Washer onto the 5/8"-18 threads of the shock stud. Apply Red Loctite to the 5/8" threads of the stud. Thread the Shock Stud into the threaded hole of the Lower Mount. Repeat on both sides and torque the Shock Stud to 65-75 ftlbs.



25. Insert 2 narrow R-Joint Spacers into the R-Joint of one end of each Lower Bars. Insert the Rear Lower Bar R-Joint into the Lower Axle Bracket. Line the through hole of the R-Joint with the of holes of the Axle Bracket. Install a 5/8" Flat Washer on to a 5/8"-18 x 3" Hex Bolt, insert into the lined up holes. Install a 5/8" Flat Washer followed by a 5/8"-18 Thin Jam Nylok Nut. Repeat on both sides and tighten the Bolts/Nuts enough to eliminate any gaps.



26. The Kit includes (4) T-busings for the front leaf spring mount. Insert a t-bushing in each front leaf spring mounting hole with the large OD to the outside.



Wishbone Axle Mount Installation



27. Insert the long R-Joint Spacers into the front of the lower bar with the small OD inserted into the R-joint. Insert the Front Lower Bar R-Joint into the Front Leaf Spring Mount. Line the through hole of the R-Joint with the of holes of the leaf spring mount. Install a 5/8" Flat Washer on to a 5/8"-18 x 5" Hex Bolt, insert into the lined up holes. Install a 5/8" Flat Washer followed by a 5/8"-18 Thin Jam Nylok Nut. Repeat on both sides and tighten the Bolts/Nuts enough to eliminate any gaps.



28. Insert the rear of the Wishbone into the Axle Bracket lining up the holes. Install a 1/2" Flat Washer on each of (2) 1/2"-13 x 3 1/4" Bolts. Insert them into each Bracket/Bushing hole from the outside with the threads pointing to the center. Install a 1/2" Flat Washer and 1/2"-13 Nylok Nut on the threads of each bolt and tighten to 50 ftlbs.



29. Remove the top (7) bolts of the differential cover leaving in the bottom (3). The emergency cable will NOT be reattached to the top bolt of the axle. It will get relocated later.


IF THE DIFFERENTIAL COVER HAS A GASKET BETWEEN IT AND THE HOUSING, IT WILL NEED TO BE REMOVED AND SEALED WITH RTV SEALANT. Be sure to refill the differential with the correct gear oil before driving.



Wishbone & Shockwave/Coilover Installation



30. Position the Axle Bracket/Wishbone in place with the wishbone to the front of the truck. Install a 8M Lock Washer & 8M Flat Washer on each of (7) M8 x 40mm bolts. Line up the (7) holes in the axle bracket with the (7) threaded holes of the Differential. Thread the (7) Bolt/washers into each of the holes. Torque to 333 inlbs



31. Insert (2) Narrow R-Joint Spacers into each side of the Wishbone's R-Joint with the small OD inserting into the R-Joint. Insert the Wishbone's Front R-Joint into the mount on the crossmember. Line the through hole of the R-Joint with the of holes of the crossmember. Install a 5/8" Flat Washer on to a 5/8"-16 x 3" Hex Bolt, insert into the lined up holes. Install a 5/8" Flat Washer followed by a 5/8"-18 Thin Jam Nylok Nut. Tighten the Bolts/Nuts enough to eliminate any gaps.




32. Insert the 1/2" ID Shock Bearing Spacers into the Bearing of the ShockWave/CoilOver. Install a 1/2" Flat Washer on a 1/2"-13 x 2 3/4" Bolts. Insert the top of the shock into the shock mount on the c-notch with the adjusting knob to the outside. Line up the holes and insert the bolt/washer. Install a 1/2" Flat Washer and 1/2"-13 Nylok Nut on the threads and tighten to 50 ftlbs.



Shockwaves/Coilovers & Carrier Bearing Mount



33. The Shock Stud requires spacers that are .400" long (90002067). Install a 5/8" ID 90002067 spacer (**Small side towards shock body**) onto the lower Shock Stud. Slide the bottom of the Shock onto the Stud. Install a second 5/8" ID 90002067 Spacer onto the Stud (**small side towards shock**). You may need to jack the rearend up to Slide the Shock onto the Stud.



34. Install the 7/16" Flat washer and 7/16" Nylok nut. Tighten the upper and lower shock bolts. Torque the Upper Bolt to 50 ftlbs and the Lower Nut to 40 ftlbs. The designed ride height of the CoilOver/Shockwave is 14 1/2" center to center.




**TRUCKS WITH CARRIER BEARINGS ONLY!
IF YOUR TRUCK DOESN'T HAVE A CARRIER BEARING, SKIP TO STEP 38**


35. The driveshaft carrier bearing will need to be relocated to optimize driveline angles at your new lower ride height. Refer to steps 35-37 for carrier bearing mount installation. Unbolt the carrier bearing retaining the OEM hardware. Center the new mount on the OEM mount. Use the OEM slots as a reference. Mark the holes and the inner edge of the mount.



Carrier Bearing, Emergency Brake Cable Relocation



36. Image 36 illustrates drilling and cutting the OEM carrier bearing mount. Drill the (4) marked holes using a 3/8" drill bit. Cut along the line that was marked along the inner edge of the new mount. This will remove the center of the OEM mount.



37. The new carrier bearing bracket is then bolted onto the remaining tabs. Attach the bracket using 3/8"-16 x 1" Bolts, Flat Washers, & 3/8"-16 Nylok Nuts. The carrier bearing mount is rotated 180 degrees and attached to the supplied bracket with the OEM hardware as shown in the picture in **Image 37**. The kit includes a Transmission Spacer that will need to be used in conjunction with the carrier bearing mount. Install it by loosening the hardware that attaches the transmission mount of the transmission crossmember. Jack up the rear of the transmission just enough to slide the spacer in and tighten the hardware.



38. Steps 38-43 cover the emergency brake cable relocation. The cables need to be relocated to gain Shockwave/CoilOver clearance. Start by removing the bolt that clamps the passenger side cable to the driver side axle tube. Spread out the clamp to remove it from the cable. Retain the bolt and clamp, they will be reinstalled.



Emergency Brake Cable Relocation

39.



39. Disconnect the top cable from the cable yoke. This can be done by twisting the top of the yoke to the rear enough to get the cable out.

40.



40. Disengage the cable from the frame mount and pull it out. The cable runs over the top of the axle from the factory, it needs to be pulled out and rerouted under the axle. Reroute the cable under the axle and reinsert in into the frame mount and connect to the yoke.

41.



41. Reinstall the removed clamp with the ears pointing upward. Install the clamp on the cable and close it with a pair of pliers. Reattach the clamp to the OEM mount using the OEM hardware.



Emergency Brake Cable Relocation, Bed Modification



42. Use the supplied clamp to attach the cable to a differential cover bolt. The clamp will wrap around the metal sheath and attach to the bolt furthest to the right that isn't being used by the differential mount. Remove the bolt from the cover and stick it through the holes in the clamp. Reinstall the bolt in the cover and tighten.



43. The Driver side emergency brake cable only requires the clamp be moved on the cable. Remove the attaching bolt and spread out the clamp enough to allow it to be moved. Move the clamp from the metal area to the rear edge of the plastic sheath. The rear edge of the clamp will line up with the rear edge of the sheath. Use the OEM bolt to reattach it.




44. The heat shield will need to be removed from the bottom side of the bed.



Bed Modification

45.




44. Trimming of the bed brace that is in between the wheel wells is necessary to clear the c-notches and wishbone. We cut ours with a diegrinder. **Image 45** shows the passenger side, the dimensions are the same for both driver and passenger. The first notch starts 2 1/2" from the end of the brace. The notch is 7" long. The second is 6" from the end of the first notch, or 15 1/2" from the end. The second notch is 2 1/2" wide. Trim the driver and passenger side using these dimensions. **Image 46** shows the driver and passenger sides cut out.

46.



46. Your bed brace should look like **Image 46** after cutting.

47.



47. Install the Bumpstops into the C-Notch above the axle using the 3/8" Flat Washer and 3/8"-16 Nylok Nut supplied. A bumpstop will need to be installed in each c-notch.



48. Reinstall the bed.

49. Set ride height on the truck. The ride height of the Shockwave/CoilOver is approximately 14 1/2". If you are using Shockwaves, this is done by changing the air pressure in the Shockwaves. If you are using CoilOvers, the ride height is done by using the adjuster nut for the coil spring. The coil spring on the CoilOver will have some preload in the spring to get ride height, this is normal.



Part # 11386510 - 99-06 Silverado Rear CoilOvers

Recommended Tools



99-06 Silverado HQ Series Rear Coilovers Installation Instructions

Table of contents

Page 36..... Included components

Page 37..... Assembly and Adjusting


Page 38..... Final Adjusting and Preloading the Spring





Major ComponentsIn the box

Item #	Part #	Description	QTY
1	24159999	5.2" Stroke HQ Series Shock	2
2	90002024	Shock Eyelet	2
4	59120225	Coilspring 12" 225lb	2
5	70010828	Delrin Spring Washer	4
6	90002222(kit)	Lower Spring Adjuster Nut (90002222 kit)	2
7	90002222(kit)	Adjuster Nut Locking Screw (90002222 kit)	2
8	90002222(kit)	Retaining Ring (90002222 kit)	2
	90002043	1/2" ID Upper Bearing Spacers	4
	90001994	5/8" ID Bearing (installed in shock and eyelet)	4
	90001995	Bearing Snap Ring (installed in shock and eyelet)	8



Assembly...



First using the supplied lower adjuster nut(90002222) thread the nut onto the shock from the bottom side as seen in figure 1.



Next install delrin washers then coil spring over the top of the shock as seen in figure 2.



Before the upper spring mount can be installed screw the adjuster knob on the upper eye mount to the firmest setting (clockwise) as seen in figure 3. Then remove the Knob.



Once the knob is removed slide the Derlin washer over the spring, Next slide the upper spring mount (90002222) over eyelet as seen in figure 4.



Install upper spring mount retainer clip (90002057) into the groove on the upper eyelet as seen in figure 5. Then reinstall adjuster to complete assembly. **NOTE:** Remember to adjust the shock valving before driving, the shock is currently set to full stiff.

Shock adjustment 101- Single Adjustable

Rebound Adjustment:

How to adjust your new shocks.

The rebound adjustment knob is located on the top of the shock absorber protruding from the eyelet.

You must first begin at the ZERO setting, then set the shock to a medium setting of 12.



-Begin with the shocks adjusted to the ZERO rebound position (full stiff). Do this by rotating the rebound adjuster knob clockwise until it stops.



-Now turn the rebound adjuster knob counter clock wise 12 clicks. This sets the shock at 12. (settings 21-24 are typically too soft for street use).

Take the vehicle for a test drive.



-if you are satisfied with the ride quality, do not do anything, you are set!

-if the ride quality is too soft increase the damping effect by rotating the rebound knob clock wise 3 clicks.

Take the vehicle for another test drive.



-if the vehicle is too soft increase the damping effect by rotating the rebound knob clock wise 3 additional clicks.



-If the vehicle is too stiff rotate the rebound adjustment knob counter clock wise 2 clicks and you are set!

Take the vehicle for another test drive and repeat the above steps until the ride quality is satisfactory.

Note:

One end of the vehicle will likely reach the desired setting before the other end. If this happens stop adjusting the satisfied end and keep adjusting the unsatisfied end until the overall ride quality is satisfactory.



Final Tightening and Adjusting

Ride Height

We have designed most cars to have a ride height of about 2" lower than factory. To achieve the best ride quality & handling, the shock absorber needs to be at 40-60% overall travel when the car is at ride height. This will ensure that the shock will not bottom out or top out over even the largest bumps. Measuring the shock can be difficult, especially on some front suspensions. Measuring overall wheel travel is just as effective and can be much easier. Most cars will have 4-6" of overall wheel travel. One easy way to determine where you are at in wheel travel is to take a measurement from the fender lip (center of the wheel) to the ground. Then lift the car by the frame until the wheel is just touching the ground, re-measure. This will indicate how far you are from full extension of the shock. A minimum of 1.5" of extension travel (at the wheel) is needed to ensure that the shock does not top out. If you are more than 3" from full extension of the shock then you are in danger of bottoming out the shock absorber.

Adjusting Spring Height

When assembling the CoilOver, screw the spring retainer tight up to the spring (0 preload). After entire weight of car is on the wheels, jounce the suspension and roll the car forward and backward to alleviate suspension bind.

- If the car is too high w/ 0 preload then a smaller rate spring is required. Although threading the spring retainer down would lower the car, this could allow the spring to fall out of its seat when lifting the car by the frame.
- If the car is too low w/ 0 preload, then preload can then be added by threading the spring retainer up to achieve ride height. On 2.6" - 4" stroke shocks, up to 1.5" of preload is acceptable. On 5-7" stroke shocks, up to 2.5" of preload is acceptable. If more preload is needed to achieve ride height a stiffer spring rate is required. Too much preload may lead to coil bind, causing ride quality to suffer.